

Installation Instructions

BE SURE TO INSERT SCREWS
INTO PILOT HOLES

1" screws
Cover screws with "snap" caps.

